



**Knob Set**

All of our Mortice/Rim knob sets come supplied with threaded spindles which fit through your latch and allow the knob sets to be screw fitted on either end. They are then fixed in place by way of a grub screw in the base of the knob.

**Loose Roses**

Used to finish the look of your knob sets and are screw fixed to your door.

**Threaded Spindle**

A standard threaded spindle for use solely with knob sets and on doors with a maximum thickness of 44mm (larger doors can be accommodated - see accessories section of our website for more sizes).

**Faceplate**

Once the latch is fitted into the door affix the faceplate to neaten up the edge.

**Wood Screw Fixings**

Supplied with matching countersunk wood screws to affix the rose plate to your door.

**Grub Screw**

This is fitted to allow you to secure the knob onto the threaded spindle. It stops movement of the knob to allow the spindle/latch to do all the turning. Loosen the screw to fit the knob then lightly tighten into the 'V Groove' of the spindle. Do not overtighten.

**Horizontal Mortise Latch**

Designed to be used with any of our knob sets or 'sprung' lever handles on rose. Mortised into the door and screw fixed in. Allows the knob or lever to be positioned well away from the frame.

**Receiver Plate**

Screw fixed to the frame of the door to allow the latch to be received.

**Horizontal Latch - 3 Lever**

A standard 3 lever horizontal latch ideal for use with door knob sets or any lever handles on rose. Due to where the latch positions the spindle it means this is ideal to keep the door knob set or lever handle on rose well away from the edge and therefore the frame of your door. Avoids knuckles being scraped against architrave when opening your door.

---  
Product Assembly

---  
Screw or Bolt Fixings

From the  
**Anvil**<sup>®</sup>

Specialist Manufacturers of Ironmongery & Lighting



**2.5" Latch**  
Backset: 44mm

This means the centre of your door knob or lever handle will be positioned 44mm away from the edge of your door. If your knob set is too close to the edge of the door you may bang or scrape your knuckles on the architrave each time you open the door.



**5" Horizontal Latch**  
Backset: 102mm

This means the centre of your door knob or lever handle will be positioned 102mm away from the edge of your door. This is useful to stop the user scraping or banging their knuckles when operating the door.

**Horizontal Latch - 3 Lever**

The measurement in the latch name (2.5", 5" etc.) refers to the actual size of the latches case, whereas the critical measurement for positioning of your knob set or lever handle is the 'Backset'. This backset dictates the position of your ironmongery in relation to the edge of your door. When choosing a

latch for use with a knob set we strongly recommend using a 3" latch or bigger to avoid scraping your knuckles on any door architrave or moulding when you turn the knob to open the door. A big latch should give you enough clearance to avoid this and the horizontal latch would do the job perfectly.