



2.5" Latch
Backset: 44mm

This means the centre of your door knob or lever handle will be positioned 44mm away from the edge of your door.



3" Latch
Backset: 56mm

This means the centre of your door knob or lever handle will be positioned 56mm away from the edge of your door.



4" Latch
Backset: 81mm

This means the centre of your door knob or lever handle will be positioned 81mm away from the edge of your door.



5" Latch
Backset: 106mm

This means the centre of your door knob or lever handle will be positioned 106mm away from the edge of your door.

Tubular Mortice Latch - Sizing Guide

The measurement in the latch name (2.5", 3" etc.) refers to the actual size of the latches case, whereas the critical measurement for positioning of your knob set or lever handle is the 'Backset'. This backset dictates the position of your ironmongery in relation to the edge of your door. When choosing a

latch for use with a knob set we strongly recommend using a 3" latch or bigger to avoid scraping your knuckles on any door architrave or moulding when you turn the knob to open the door. A 3" latch should give you enough clearance to avoid this.